


John-Ease Calf Chute Instructional Manual


One-man calf processing system. Process approximately one calf per minute by yourself.
(Best for working calves 60 days of age and under.)

Pen setup for best results

Right handed chute



Left handed chute



10-step processing plan

1. Place no more than 10-12 calves in approximately 14' x 14' pen at one time.
2. **Sort one calf from holding area**, walk the calf into the corner of the pen most directly in front of the calf chute without touching the calf at all.
3. As the calf turns his direction toward the calf chute, gently grab his tail with one hand and guide him toward the chute and along the fence by walking beside him, using your hand on his tail for motivation.
4. As you pass the swinging gate, pull the gate across behind you, swinging it all the way around as you go, forcing the calf into the corner directly behind the chute.
5. When the calf approaches the corner behind the chute, he will naturally turn and cut back towards the calf chute.
6. During the time the calf is turning toward the chute, maintain your hand on his tail, while moving your knees against his side, and at the same time gently guide the calf's head towards the head gate. The calf will naturally lunge forward seeking to escape through the daylight in the head gate.
7. When the calf's head enters the head gate, quickly pull the head gate handle latching it comfortably on the calf's neck.
8. Turn and latch the swinging gate to the notched pivotal strap, located on the angled side panel. Then press inward. The calf is tightly secure.
9. You can then easily process the calf with all processing tools comfortably within reach.

Removal of calf from calf chute

10. Release the head gate first. Then the swinging gate from the notched pivotal strap. Calf will naturally back up as gate swings open. Release calf back into the pen or into adjacent pen if preferred.